



	PART	DESCRIPTION	Q'TY USED	NOTE
1	H60 -1	Head Assembly		
2	H60 -2	Slide Plate	1	
3	H60 -3	Camera Screw (3/8-16 UNC)	1	
4	H60 -4	Locking Knob, Slide Plate	1	
5	H60 -5	Locking Knob, Tilt	1	
6	H60 -6	Shift Knob, Pan Drag	1	
7	H60 -7	Locking Knob, Pan	1	
8	H60 -8	Fixing Handle, B-leveler	1	
9	H60 -9	Level	1	