



|    | PART    | DESCRIPTION               | QTY USED | NOTE |
|----|---------|---------------------------|----------|------|
| 1  | H70 -1  | Head Assembly             |          |      |
| 2  | H70 -2  | Slide Plate               | 1        |      |
| 3  | H70 -3  | Camera Screw (3/8-16 UNC) | 1        |      |
| 4  | H70 -4  | Locking Knob, Slide Plate | 1        |      |
| 5  | H70 -5  | Locking Knob, Tilt        | 1        |      |
| 6  | H70 -6  | Shift Knob, Tilt Drag     | 1        |      |
| 7  | H70 -7  | Shift Knob, C-Balance     | 1        |      |
| 8  | H70 -8  | Shift Knob, Pan Drag      | 1        |      |
| 9  | H70 -9  | Locking Knob, Pan         | 1        |      |
| 10 | H70 -10 | Fixing Handle, B-Leveler  | 1        |      |
| 11 | H70 -11 | Level                     | 1        |      |