



	PART	DESCRIPTION	Q`TY USED	NOTE
1	H40 -1	Head Assembly		
2	H40 -2	Slide Plate	1	
3	H40 -3	Camera Screw (1/4-20 UNC)	1	
4	H40 -4	Camera Screw (3/8-16 UNC)	1	
5	H40 -5	Locking Knob, Slide Plate	1	
6	H40 -6	Locking Knob, Tilt	1	
7	H40 -7	Locking Knob, Pan	1	
8	H40 -8	Fixing Handle, B-Leveler	1	
9	H40 -9	Level	1	